


How to update your BT2400 and BT2410 Series tester.



1. Launch PC Software
2. Update Software
3. Select File
 - Select the new tester firmware file provided by DHC.

Note

1. Do not decompress the zip file.
2. This update process does not apply to BT2400 Pro.

Warning

Using firmware files from unknown sources may cause permanent damage to the tester.